

Restore QuickScan® Mobile default



Enter configuration



Set Radio Address



+

four digits for the QuickScan® Mobile Address
(from 0000 to 1999).

All readers used in the same area must have different addresses.

Exit and Save configuration



5. Read the **Bind** code to pair the QuickScan® Mobile reader to the cradle.
The reader is dedicated to the cradle. Any previously **bound** reader will be excluded.

Bind



The green LED on the QuickScan® Mobile reader will blink: the reader is ready to be positioned onto the cradle.

6. Firmly position the reader onto the cradle within 10 seconds, a beep will be emitted, signaling that the QuickScan® Mobile cradle has been paired to the QuickScan® Mobile reader.

7. Now scan the following barcode:

Enter Configuration



8. Now scan the following barcode:
one character header



9. Now scan the numbers 2 and 3 on the right side of this paper.

10. Now scan the following barcode:

one character terminator



11. Now scan the numbers 2 and 5 on the right side of this paper.

12. And finally scan this barcode:

Exit and Save Configuration



0



1



2



3



4



5



6



7



8



9

